

Configuring Traktor 2 for the DJControl MP3 LE (Windows version)


(Updated: October 2014 for version 2.68)

1- Configuration of the MIDI channel

From the DJ Console control panel, make sure that **MIDI channel for controls** is set to **1**.

This is very important as the profile provided is configured for the DJControl MP3 LE to work on this channel.

If you have multiple MIDI controllers, or would like to use the DJ Console on a different MIDI channel, you will need to modify the profile accordingly. Consult Traktor's user manual for more details.



2- Audio configuration in Traktor

As the DJControl MP3 LE is only a MIDI controller, you will need to configure Traktor's audio setup in order to use your sound card for playback and monitoring on separate stereo channels (Consult the user manual for more details).



3- Configuration of the Midi controllers in Traktor Pro 2 (Version 2.68)

a. At the bottom of the configuration menu, click the **Import** button to locate and select the **.TSI** configuration file.




b. **Controller Mapping, MIDI Device Setup** and **Effects Settings** should be selected before clicking OK

c. In **Controller-Manager**:

-For Device, select **DJ Control MP3 LE- Generic MIDI**

- Do the same for both **In-Port** and **Out-Port**.



This menu also give you access to the various MIDI settings, should you wish to modify them.
(Consult chapter **13.21 – Controller Manager** of the user manual for more details)



MIDI Layout for the DJ Control MP3 LE and Traktor Pro2

NOTE: The terms used are those employed in Traktor

Main Configuration:

- A-** Tempo (Reset)
- B-** Tempo
- C-** Tempo Bend (Down/Up)
- D-** Sync
- E-** Seek position (Backward/Forward)
- F-** EQ (Bass/ Mid/ Treble) and EQ Kill
- G-** Scratch On/Off
- H-** Jog Turn
- I-** Monitor Cue
- J-** Load Selected
- K-** Volume Fader
- L-** Cue
- M-** Play/Pause
- N-** X-Fader




Scratch:



CUE + Jog Wheel : Jog Turn (Scratch)



Navigation/ browser:



Folder navigation

Folder + ↑ ↓ : Step browsing

Folder (A) + Left Jog Wheel:
Fast browsing

Folder (A) + LOAD A:
Expand/Collapse

Playlist navigation (Default)

↑ ↓ : Step browsing

File (B) + Right Jog Wheel:
Fast browsing




Loops / FX:

1- Loop Set (In/Out)

2- Filter (Press and hold)

You can modify the value of the filter using the deck's **PITCH** knob.

3 -4 : Loop Size (- /+)




5- Effect 1 On

6- Effect 2 On

7- Effect 3 On

8- Effect unit 1 On (Deck A) / Effect unit 2 On (Deck B)



Secondary functions:


Press and hold **Automix** to access the secondary functions

A- Monitor Mix

B- Monitor Volume



Midi controllers map



Deck A**Deck B**

- | | |
|----------|------|
| 1) C# -1 | A 0 |
| 2) D -1 | Bb 0 |
| 3) Eb -1 | B 0 |
| 4) E - 1 | C 1 |
| <hr/> | |
| 5) F -1 | C# 1 |
| 6) F# -1 | D 1 |
| 7) G -1 | Eb 1 |
| 8) G# -1 | E 1 |

