




DJ Pro

Hercules DJControlWave




Mapping Description rev 1.0





- MIXER Mapping**



SHIFT_LEFT + ENCODER_DECKA = BROWSE


SHIFT_RIGHT + ENCODER_DECKA = BROWSE

SHIFT_LEFT + PLAY DECKA = LOAD Deck A

SHIFT_LEFT + PLAY DECKB = LOAD Deck B



- DECK Mapping




EFFECT_MODE

SAMPLE_MODE

CUE_MODE

PERFORMANCE BUTTONS 1 to 3



PITCH FADER

ENCODER DECKX

CAPACITIVE TOUCH WHEEL

SYNC


CUE STOP

PLAY / PAUSE




- Detailed Buttons Modes:

'FX' Mode




Pad 1 to 3 = Fx 'ON' (Fx 1 to 3)

'Sample' Mode



Pad 1 to 3 = Sample Play Now 1 to 3

'CUE' Mode



Pad 1 to 3 = HotCue 1 to 3

SHIFT_LEFT + HotCue 1 to 3= **DELETE CUE** 1 to 3



'Loop' Mode



ENCODER_DECKX = Loop Half/Double the size of the loop

PUSH+ ENCODER_DECKX = Loop ON/OFF