

This is the configuration for the standard version of Traktor with the DJ Console. This will allow the console to work as a MIDI controller.


- 1- First set the DJ Console mixer in other for the console to use the ASIO driver and to become a MIDI controller.



- 2- Launch Traktor and access the setting menu




3- Set the software AUDIO and INPUT menu accordingly.



The LOAD button needs to be used if the user wants to use the preset available from our site. Otherwise, he will need to manually configure all the commands according to his liking. In this case, ask him to check the Traktor documentation to learn how to set a MIDI controller.

Additional settings (Toggle, incremental, etc) can also be applied to certain functions.



Additional settings are available in the PREFERENCE tabs

layout for DJConsole.tks



A: loop length

B: loop on/off

C: EO

D: Gain

E: Cue Set

F: Play/Pause

**G: Cue Selection
(Headphones)**

H: Key lock

I: Sync

J: Pitch

K: Previous/Next

L: Pitch Bend

M: Crossfader

N: Position

(The terms used in this document are those used in Traktor)

