

HERCULES®

嗨酷乐


DJCONTROL INSTINCT P8

Quick Start Guide
快速入门指南




BEFORE USING YOUR
DJCONTROL INSTINCT P8


使用 DJCONTROL INSTINCT P8
之前的准备工作




Connect DJControl Instinct P8 to your computer
将 DJControl Instinct P8 连接到您的计算机




Connect your speakers
连接音箱




Connect your headphones
连接耳机



Go to / 访问
<https://support.hercules.com/djcontrolinstinctP8>




Download and install DJUCED™ 40°
下周并安装 DJUCED™ 40°



DJCONTROL INSTINCT P8

40°
DJUCED™
BOOST YOUR MIX



1. Mixer 2. Effects rack 3. Sampler Deck C/D 4. Track Deck A/B 5. Browser

1. 混音器 2. 音效架 3. 采样器转盘 C/D 4. 曲目转盘 A/B 5. 浏览器

- | | |
|---|--|
| 1. Transport buttons: SYNC, CUE, play/pause | 1. 走带按钮: SYNC、CUE、播放/暂停 |
| 2. Performance pads | 2. 打击垫 |
| 3. Transport button: SHIFT | 3. 走带按钮: SHIFT |
| 4. Adjust loops/filter/effects amount | 4. 调节循环/滤波器/音效数值 |
| 5. Browse within the library, load tracks, adjust master volume | 5. 浏览曲库、加载曲目、调节主音量 |
| 6. 3-band equalization | 6. 3 波段均衡器 |
| 7. Mixer: headphones volume, monitoring, volume faders, crossfader, SCRATCH, MODE | 7. 混音器: 耳机音量、监听、音量推子、交叉推子、SCRATCH、MODE |
| 8. Deck: Scratch, Pitch bend, Pitch Reset | 8. 转盘: Scratch、Pitch bend、Pitch Reset |
| 9. Speakers output (1-2) | 9. 音箱输出 (1-2) |
| 10. Bus-powered USB port | 10. USB 总线供电端口 |
| 11. Headphones output (3-4) | 11. 耳机输出 (3-4) |



Full user manual available at <https://support.hercules.com/djcontrolinstinctP8>
此处可下载完整的用户手册: <https://support.hercules.com/djcontrolinstinctP8>

