







DJCONTROL INSTINCT

- | | | |
|---------------------------------|---------------------------|--------------------------------------|
| 1- Pressure-detecting jog wheel | 8- Explorer | 17- Cue point |
| 2- Multifunctional buttons | 9- Load on deck | 18- Play/pause |
| 3- Multifunctional buttons | 10- Headphones previewing | 19- Headphones output (channels 3-4) |
| 4- Headphones volume | 11- Deck volume | 20- Speakers output (channels 1-2) |
| 5- Scratch mode On/Off | 12- Crossfader | 21- RCA output |
| 6- Multifunctional buttons | 13- Pitch | 22- Kensington® lock |
| mode selection | 14- Pitch Bend +/- | 23- Fixed USB cable (1.83 m) |
| 7- 3-band equalizer | 15- Fast-forward/rewind | |
| | 16- Synchronize deck | |





1 - WAVEFORM VIEWER:

- Artist name
- Duration
- Song name
- BPM
- Album
- Full track preview
- Waveform
- Beatmarks

2 - SAMPLER

4 samples/deck

- Volume
- Play
- Record
- Loop

3 - DECK

- Jog wheel - Pitch fader - Synchronize
- Cue points
 - Set Cue point
 - Delete Cue point
- Play/Pause - Stop
- Loop area
 - Loop in/out
 - Loop length
 - Split into 4 samples

4 - BROWSER

5 - EFFECT SLOT

6 - MIXER

- Equalization
- Volume faders
- Headphones control
- Crossfader

7 - SEQUENCER