

My speakers have been connected correctly to my sound source, but I still cannot get any sound after having turned it ON.

Once your system has been turned ON, the LED underneath the remote docking station should lit up in a pale blue shade, indicating the system is in standby mode.

Press the center button of the remote control for a few second so the LED at the center becomes RED.



The bottom of the docking station will become bright blue. The system is now active.

The LEDs will also blink to indicate changes are being made (volume, equalizer, etc).