

How can I verify that my webcam has been installed correctly on my computer?

You can check that it is the case from Windows **Device Manager**:

- Right click on **MY COMPUTER** icon on your desktop and select **Properties**
- If you are using Win ME: Select the **Device Manager** tab
- If you are using Win 2000 or XP: Select the **Hardware** tab, then click on the **Device Manager** button

Webcam Classic

Under **Imaging Devices**, you should normally get the following:



Webcam Deluxe

As with the Classic model, the webcam should also appear under **Imaging Devices**.

Since the Deluxe model incorporate a microphone, it will show under **Sound, Video & Game Controller**, as well as a **Composite USB Device**:

