


## [Virtual DJ - Using and recording external sources \(Microphone, Line In/Phono\)](#)

The following document explains how to use external sources with the bundled version of **Virtual DJ LE** or **Virtual DJ Pro Full**.

It is first necessary to configure Virtual DJ accordingly:

- 1- Open the **CONFIG** menu.
- 2- Under **Sound Setup**, apply the following configuration:



Click **APPLY** to confirm.

### [Using a Microphone:](#)


- 1- **Turn On** the microphone by pressing the **Mic On/Off** button and adjust the microphone level using the **Vol** knob.



This mode is similar to **Talk Over**, which means the microphone signal can be heard over the mix (Output 1-2). You will not be able to hear the microphone in your headphones.

- 2- If you wish to record the microphone signal, press **Source 1**.

You will notice that **Deck A** now displays **Microphone**, indicating that it is now used as an **external source**. This also means the microphone signal can be recorded and cued in the headphones.



Adjust the microphone level using the **Vol** knob. If necessary, you can also use the **Gain** knob or modify the equalisation using the deck's **Bass**, **Medium** and **Treble** controls.



3- Once you are happy with the configuration, click **REC** to start recording. Click the button again when you are done.


4- Pressing either **Source 1** or **Mic On/Off** will default back to Talk Over mode. Press **Mic On/Off** once more when you want to use Deck A for playing MP3s.

### Using Line In/Phono:

1- To start using your external source, press **Source 1**.



**Deck A** now displays **LineIn 1**, indicating that it is now used as an external source. This also means the signal from this source can be recorded.



2- Adjust the the **Gain** knob or modify the equalisation using the deck's **Bass**, **Medium** and **Treble** controls.

3- Once you are happy with the configuration, click **REC** to start recording. Click the button again when you are done.

4- Press **Source 1** again when you want to use Deck A for playing MP3s.

