HERCULES UNIVERSAL DJ

**DJUCED™ 40° <> Hercules Universal DJ**

Mapping Description rev 1.1

DECK A

MIXER

DECK B

- **MIXER Mapping**

3-Band EQ

Scratch ON/OFF

RECORD

MAGIC FADE

BROWSE UP/DOWN +
TOGGLE FILES / FOLDER

LOAD DECK

PFL

Deck Volume

Deck Vumeter

Cross Fader

- **DECK Mapping**

PAD MODE SELECTION

CONTEXTUAL ENCODER

(*Detailed in Pad modes below*)

PITCH FADER

PERFORMANCE PADS 1 to 8

CAPACITIVE TOUCH WHEEL

PLAY / PAUSE

CUE STOP

SYNC

SHIFT

- **Detailed Pads Modes:**

'CUE' Mode

Pad 1 to 8 = HotCue 1 to 8

Encoder = Gain

'Shift' + Pad 1 to 8 = Delete HotCue 1 to 8

'Shift' + Encoder = Gain

'FX' Mode

Pad 1 to 3 = Fx 'ON' (Fx 1 to 3)

Pad 4 = Macro Fx 'ON'

Pad 5 to 7 + **Encoder** = FX Amount (Fx 1 to 3)

Pad 8 + **Encoder** = Macro Fx Amount

Encoder = Dry / Wet

'Shift' + **Pad** 1 to 3 = Fx Selection List increment (Fx 1 to 3)

'Shift' + **Pad** 5 to 7 = Fx Selection List decrement (Fx 1 to 3)

**'Shift'** + **Encoder** = Gain

'Sample' Mode

Pad 1 to 4 = Sample Play Now 1 to 4

Pad 5 to 8 = Single shot / Loop sampler 1 to 4

Encoder + **Pad** 5 to 8 pressed = Sample Volume 1 to 4

'Loop' Mode

Pad 1 to 8 = Loop 1/16 to Loop 16

Encoder = Loop Half/Double if a loop is 'ON' or Loop Select if no loop is 'ON'

'Shift' + **Pad** 1 = Loop In

'Shift' + **Pad** 2 = Loop Out,

'Shift' + **Pad** 3 = Loop Half (/2)

'Shift' + **Pad** 4 = Loop Double (x2)

'Shift' + **Pad** 5 = Loop Toggle

'Shift' + **Pad** 6 = Loop Mode (LOOP / RUN)

'Shift' + **Pad** 7 = Loop Split

'Shift' + **Pad** 8 = Easy Loop ON/OFF

'Shift' + **Encoder** = Gain